

How to Report an ELD Malfunction

Step 1

Tap on the “Help” button on the top right corner



Step 2

Enter any notes you need to regarding the malfunction



Step 3

Tap on the save button. This sends the report to us

